

ELECTRIC SLAG FURNACE DIMENSIONING



A.K. Kylo, N.B.
Gray, and A.
Filzwieser,
*Proceedings of EMC
2005*

Mark William Kennedy
Norwegian University of Science and Technology





March 11-15 | Orlando, Florida

Outline

1. Introduction to modern slag furnace designs
2. 'Work' and 'Losses' in the furnace
3. Slag furnace dimensioning steps
4. Use of electrode ratio method
5. Types and sizing of electrodes
6. Slag 'resistance' furnaces – What is the nature of the resistance and how does this create uncertainty in our designs?



Typical Electric Furnace Electrode and Body Arrangements



- a) single top entering electrode (1-phase),
- b) two electrodes (1-phase),
- c) **three electrodes (3-phase)**, and
- d) six-in-line electrodes (3-single phase).



Furnace Generations and Indicative Intensity


Furnace Generation	Energy Intensity (kW/m ² of hearth area)	Typical Side Wall Heat Flux (kW/m ²)
1	~100	<15
2	~200	<20
3	300-400	~30-60
4	500-1000	>30

(4) experimental


Energy intensity and total furnace power have been increasing in order to **decrease furnace sizes** and **increase thermal efficiency**.

Modern High Intensity Slag Furnaces

Side Wall Cooler EXAMPLE




With Permission of MacRae Technologies



Elkem Multi-Purpose Furnace®

Textured Panels – Example by Tenova - Pyromet



**Complete bathline for a
12 m diameter slag furnace**




Maxicool[®] cooling panels for a 12m dia. slag cleaning furnace



TIMS 2012
141st Annual Meeting & Exhibition

March 11-15 | Orlando, Florida

Composite Furnace Modules (CFM) with FEM modelling results by Bateman



Bateman Copper Cooler Technology, company brochure



TMS 2012
141st Annual Meeting & Exhibition

March 11-15 | Orlando, Florida

Heat in the Furnace

Work:

1. Preheat charge,
 2. Pre-reduce charge,
 3. Melt charge,
 4. Produce the superheat required to achieve tapping, and
 5. **Drive reduction reactions in the slag phase.**
- } **Higher rates = more superheat**

We can assume that the superheat is controlled by items (1)-(4).



Heat in the Furnace

Losses:

- Any heat that is not consumed productively must necessarily leave the furnace as heat losses.

Any 'mistake' in either design or operation, will increase losses!

- Cooled copper structures are the main 'sinks'.



TMS 2012
141st Annual Meeting & Exhibition

March 11-15 | Orlando, Florida

Heat in the Furnace

Work (work for melting is shown):

$$Q_{slag-charge} = A_{slag-charge} h_{slag-charge} (T_{bulkslag} - T_{liquidus})$$

Increases with power input, gas bubbles and buoyant mixing effects.

Loss (assume hot face is @ $T_{liquidus}$):

$$Q_{slag-wall} = A_{slag-wall} h_{slag-wall} (T_{bulkslag} - T_{liquidus})$$

Natural convection if properly designed and operated, magnitude independent of power input.



Slag Resistance Furnace Dimensioning steps

1. A target furnace **production rate (PR)** is chosen **[mt/h]**,
2. **Specific energy requirement (SER)** of the process is established (excluding heat losses) **[kWh/mt]**,
3. The **smallest electrode diameter** is selected **[m]**, along with the **number** and **type**,



Slag Resistance Furnace Dimensioning steps

4. Furnace **dimensions** are chosen based on an acceptable **energy intensity** [**kW/m²**] or by **standard ratios** to the **electrode** dimensions,
5. Furnace **heat losses** are estimated [**MW**], and
6. Total **furnace power** verified [**MW**].



Furnace Power

$$P_{furnace} = NP_{electrode}$$

Where **N** is the **N**umber of electrodes.

$$P_{electrode} = I_{electrode}^2 R_{electrode}$$

**‘Wye’ or
E-heat**

Andræ, 1933:
(immersed elec.)

$$R_{electrode} = \frac{k}{\pi D_e}$$

**First
and
simplest**



Electrode Resistance Varies Inversely to D_e



Furnace Dimensioning by Ratio's

R.H. Eric and A.A. Heija, 1995:

- I. $6 D_e$
- II. $7.7 D_e$
- III. $8.6 D_e$




'Active' Electrode Area
Or 'Crater' concept: $2 D_e$

P. B. Wowk, 1964



3D FEM Model Current Density at the Slag-Metal Interface



Melina Garcia, Elkem



TMS 2012
141st Annual Meeting & Exhibition

March 11-15 | Orlando, Florida

'Ratio' Rules of Thumb


- Active Electrode Area, **2-3 D_e**
- Electrode Spacing, **2.7 D_e (2.4-3.0)**
- Furnace Diameter, **6-8.6 D_e**

Using a system of ratios, everything depends on the electrode size. Electrode size is established by the possible power input per electrode, i.e. from the electrode current limitations, and furnace resistance.





Carbon Electrodes

Söderberg, 4 – 7 A/cm²
Pre-baked, ~6 A/cm²



SGL carbon electrodes

Söderberg 1923



Inventor:
Carl Wilhelm Söderberg


Atorney
Atorney



TMS 2012
141st Annual Meeting & Exhibition

March 11-15 | Orlando, Florida

Ultra-High-Power Graphite Electrodes




$$J_e \text{ (A/cm}^2\text{)} \\ = 22D_e \text{ (m)}^{-0.5}$$


$$I_e \text{ (kA)} \\ = 170D_e \text{ (m)}^{1.5}$$




Graphite Electrodes Current Carrying Capacities





Impact of Skin Effect on Electrode Resistance



What Determines Furnace Resistance?



Where are the Voltage Drops?



“It is indeed striking that the measured electric potentials only agree...if the potential applied to the slag is 100-120 V less than that applied to the electrodes.”

Y.Y. SHENG, G.A. IRONS, and D.G. TISDALE, 1998



TMS 2012
141st Annual Meeting & Exhibition

March 11-15 | Orlando, Florida

What Really is Slag 'Resistance'?

- Standard conduction losses?
(joule heating)
- Gas bubbles at the electrode surface?
- Polarization, over-potential?
- Charge transfer losses?
- Capacitance?
- Complex permittivity?
- Etc.



Conclusions

- Methods for systematically designing slag furnaces are restricted by our lack of fundamental understanding of the true nature of electrical heat production and heat transfer in slag furnaces.



Simplistic models have been presented, which might be significantly improved by targeted temperature and electrical measurements in industrial slag furnaces.



Thank You!

Contact information:

mark.kennedy@material.ntnu.no

mark.kennedy@metallurgy.no

Mobile: +4792219891



TMS 2012
141st Annual Meeting & Exhibition

March 11-15 | Orlando, Florida